



NOTES:

- SYSTEM TO BE INSTALLED PER MANUFACTURER SPECIFICATIONS. RUBBER TREE WELL BY RUBBERWAY INC. WWW.RUBBERWAY.COM
- LEAVE A 15" GAP FROM THE TRUNK OF THE TREE, TO USE A TEMPORARY SONO TUBE FORM AND REMOVE ONCE THE RUBBER HAS CURED.

NOTE

ALL INFORMATION SHOWN IS SUGGESTED. DUE TO APPLICATION VARIANCES, IT IS THE RESPONSIBILITY OF THE ENGINEER OF RECORD TO PROVIDE ALL INFORMATION REQUIRED TO SUIT LOCAL BUILDING CODES AND REGULATIONS. THIS DETAIL IS FOR REPRESENTATIVE PURPOSES ONLY AND SHOULD NOT BE SOLELY USED FOR CONSTRUCTION PURPOSES UNLESS IT HAS BEEN CERTIFIED AND SEALED BY A QUALIFIED ENGINEER.



Rubberway, Inc.
4000 Barranca Pkwy,
Ste 250
Irvine, CA 92604
Phone. 877.288.0045
rubberway.com

SHEET NAME: RUBBERWAY TREE WELL MULTI LAYER - LARGE EXISTING TREES -BETWEEN CURB AND WALKWAY

SHEET: DETAIL NO. 24

APPROVED BY: KA **DRAWN BY:** LL **DATE:** 04/22/2018

DUE TO VARIANCES IN LOCAL CODES, CONSTRUCTION PRACTICES AND REQUIREMENTS, ALL DETAILS SHALL BE CONSTRUCTED IN ACCORDANCE WITH SUCH LOCAL CODES, CONSTRUCTION PRACTICES AND REQUIREMENTS REGARDLESS OF DETAIL CONSTRUCTION SHOWN IN DRAWING. RUBBERWAY, INC. RESERVES THE RIGHT TO CHANGE SPECIFICATIONS SHOWN WITHOUT NOTICE. ALL CHANGES TO SPECIFICATIONS CAN ONLY BE APPROVED BY USSA, INC.