


**NOTES:**

- SYSTEM TO BE INSTALLED PER MANUFACTURER SPECIFICATIONS. RUBBER TREE WELL BY RUBBERWAY INC. [WWW.RUBBERWAY.COM](http://WWW.RUBBERWAY.COM)
- LEAVE A 15" GAP FROM THE TRUNK OF THE TREE, TO USE A TEMPORARY SONO TUBE FORM AND REMOVE ONCE THE RUBBER HAS CURED.

**NOTE**

ALL INFORMATION SHOWN IS SUGGESTED. DUE TO APPLICATION VARIANCES, IT IS THE RESPONSIBILITY OF THE ENGINEER OF RECORD TO PROVIDE ALL INFORMATION REQUIRED TO SUIT LOCAL BUILDING CODES AND REGULATIONS. THIS DETAIL IS FOR REPRESENTATIVE PURPOSES ONLY AND SHOULD NOT BE SOLELY USED FOR CONSTRUCTION PURPOSES UNLESS IT HAS BEEN CERTIFIED AND SEALED BY A QUALIFIED ENGINEER.



Rubberway, Inc. 4000  
Barranca Pkwy, Ste  
250  
Irvine, CA 92604  
Phone. 877.288.0045  
[rubberway.com](http://rubberway.com)

**SHEET NAME:** RUBBERWAY TREE WELL -LARGE  
EXISTING TREES - BETWEEN CURB & WALKWAY

**SHEET:** DETAIL NO. 25

**APPROVED BY:** KA

**DRAWN BY:** LL

**DATE:** 04/22/2018

DUE TO VARIANCES IN LOCAL CODES, CONSTRUCTION PRACTICES AND REQUIREMENTS, ALL DETAILS SHALL BE CONSTRUCTED IN ACCORDANCE WITH SUCH LOCAL CODES, CONSTRUCTION PRACTICES AND REQUIREMENTS REGARDLESS OF DETAIL CONSTRUCTION SHOWN IN DRAWING. RUBBERWAY, INC. RESERVES THE RIGHT TO CHANGE SPECIFICATIONS SHOWN WITHOUT NOTICE. ALL CHANGES TO SPECIFICATIONS CAN ONLY BE APPROVED BY RUBBERWAY, INC.